

**HANDBOOK  
OF THE HEIDELBERG  
AUTOMATIC PLATEN**



HANDBOOK  
OF THE HEIDELBERG AUTOMATIC PLATEN



CONTAINING INSTRUCTIONS  
FOR WORKING & COMPLETE LIST OF PARTS,  
FULLY ILLUSTRATED

THE HEIDELBERG  
AUTOMATIC PLATEN COMPANY  
43 BELVEDERE ROAD (NEAR WATERLOO STATION)  
LONDON S. E. 1

TELEGRAMS: ALAKEMAN, LAMB, LONDON / TELEPHONE: WATERLOO 1313-1316

## FOREWORD

This handbook is issued for the purpose of giving Owners of the Heidelberg Automatic Platen correct instructions for the working of the machine, thus enabling them to use the platen to its utmost capacity. It gives full information as to how to meet difficulties which might occur when working with different stocks of paper, or different sizes, and should also help the operator to handle the Heidelberg efficiently and in a proper way.


We recommend all Heidelberg Owners to apply direct to us for all requirements concerning the machine.

When spare parts are needed please quote the number of the part as per diagram and table. It is also advisable to mention the number of the machine, which is to be found on the left front edge of the base of the machine, which is to be found on the left front edge of the base of the feed table. All parts of the machine are enumerated on pages 41 to 89 and are reproduced on photographs annexed. Every part bears a number, and when ordering, for instance, "Spring for end of roller track," you only need wire:


"Send for Machine No. 7410 part 0641."

The Heidelberg Automatic Platens are built in series in large numbers, special jigs being used. After each process every part is thoroughly and carefully tested by the most accurate gauges and measuring tools. All parts of the machine are manufactured upon the interchangeability system which ensures easy fitting and the convenient changing of any part.

Every Heidelberg Automatic Platen is thoroughly tested before leaving the Works, and the absolute faultless working of every machine can be fully guaranteed.



Front View of the Machine



Side View of the Machine

## CONTENTS

	Page
Foreword . . . . .	2
The Measurements and Weights . . . . .	6
Packing of the Machine . . . . .	7
Installation of the Machine . . . . .	7
The Direct Electric Drive . . . . .	8
The Drive from Shafting . . . . .	9
Oiling of the Machine . . . . .	10
The Inking Apparatus . . . . .	12
The Ink Duct . . . . .	13
The Setting of the Distributing Rollers . . . . .	14
The Setting of the Roller Tracks . . . . .	15
The Setting of the Ductor Movement . . . . .	16
Locking and Placing Forme in the Machine . . . . .	17
The Tympan Packing . . . . .	18
The Regulation of Impression . . . . .	19
Starting and Stopping the Machine . . . . .	20
The Automatic Throw-off . . . . .	21
Preparation of the Machine for Printing . . . . .	22
Printing two-up and Printing Envelopes . . . . .	23
The Sheet Steadier . . . . .	24
The Blower . . . . .	25
Tilting of the Sucker Bar . . . . .	26
The Lifting of the Feed Table . . . . .	27
Valve on the Sucker Bar . . . . .	28
The Air Pump . . . . .	29
The Clack Valve on the Air Pump . . . . .	30
The Delivery Blower . . . . .	31/32
Delivery Appliance for Small Sizes . . . . .	33
The Resetting of the Friction Clutch . . . . .	34
The Rubber Sucker Bar . . . . .	35
Lay Standard for Small Sizes . . . . .	36
The Sheet Counter . . . . .	36
Table for Adjusting the most important Parts . . . . .	37
Index to Groups . . . . .	39
Index of Parts . . . . .	From 41

## MEASUREMENTS AND WEIGHTS

Maximum Paper Size . . . . .	10 <sup>1</sup> / <sub>4</sub> " × 13 <sup>1</sup> / <sub>2</sub> "
Maximum Type Surface . . . . .	9 <sup>1</sup> / <sub>2</sub> " × 13 <sup>1</sup> / <sub>4</sub> "
Inside Chase Measurements . . . . .	10 <sup>1</sup> / <sub>4</sub> " × 13 <sup>1</sup> / <sub>2</sub> "
Normal Output per Hour . . . . .	3000
Diameter of the Fly-wheel (Direct Drive) . . . . .	27 <sup>1</sup> / <sub>2</sub> "
Face of the Fly-wheel . . . . .	2"
Diameter of Pulley on Fly-wheel (Drive from Shafting) . . . . .	12 <sup>5</sup> / <sub>8</sub> "
Face of Pulley on Fly-wheel . . . . .	2"
Revolutions of Fly-wheel to One Impression . . . . .	6
Revolutions of Fly-wheel per Minute to give a speed equal to 2800 Impressions per Hour . . . . .	280
Power Required . . . . .	1 h. p.
Net Weight of Machine (without motor) . . . . .	approx. 1765 lbs.
Gross Weight . . . . .	approx. 2315 lbs.
Space Required . . . . .	3' 5" × 5' 3"
Height of Machine . . . . .	4' 1"
Outside Case Measurements: Width . . . . .	4' 3"
Length . . . . .	5' 1"
Height . . . . .	5' 1"

Packing of the Machine. The Machine is despatched from the Works completely fitted. By drawing out the nails, one side of the case can be removed, as illustrated, as well as the side opposite. Then the four nuts which connect the bottom of the case with the sides should be loosened. The sloping roof and the remaining sides can now easily be lifted up and placed upon one side so that the machine is easily accessible. After the four screws which hold the machine to the bottom board have been loosened, the machine can be removed. On the bottom of the case the machine accessories are also packed.

The case should be re-assembled and returned to us, if this arrangement has been made.

The Installation of the Machine. If the machine is to stand upon a wooden floor, care should be taken that it stands over two joists. If this is impossible fix the machine on a wooden frame about two inches thick, which must be tightly screwed down to the floor. The machine must be perfectly level. The position should be tested with a spirit level. This should be done by placing the spirit level in one direction upon the inking cylinder and in the other direction upon a square held against the type bed. The machine should be cleaned with paraffin and the anti-rust paint removed. Attention should be paid to the cleaning of the oil holes and the machine oiled up with the best thin acid-free machine oil. (See special Lubricating Instructions.)



Packing of the  
Machine


The Direct Electric Drive. For direct Electric Drive, fix the motor brackets 0123 and 0136 to the main frame 0101, on the flywheel side by means of shaft 0124 and its collars. This should be done in such a way that the square head screws in the main body hold shaft 0124 in position. The hook 0126 in the main frame must be connected with bracket 0136, so that the bracket is under the pressure of spring 0133. Then screw the motor to the brackets.

Care must be taken that the motor pulley is in line with the fly-wheel. The exact length of belting required is ascertained by keeping the motor brackets in a horizontal position and placing a string around the motor pulley and the flywheel rim, tightening the string and then knotting it. The motor brackets are able to oscillate in their bearings, and this allows the motor to act as a belt tightener. Motor slide rails for the electric motor are therefore not required.

The flywheel must revolve clockwise as indicated by the arrow.


The capacity of the motor should be 1 h. p. with 14-1500 revolutions per minute. To obtain this number of revolutions the diameter of the pulley of the motor should be approximately  $5\frac{1}{2}$ ".

The speed of the machine may be varied by a regulating starter. This allows a speed reduction of approximately 50% and an increase of about 15% in the case of direct current. If alternating or three phase current is used only a reduction of speed is possible, viz. by a regulation of approximately 75% of the number of revolutions. The regulation is possible at a constant direction.



The Drive from Shafting. For driving from shafting the machine is driven by a countershaft from which the belt runs to the small pulley on the flywheel. The countershaft is driven from the main shaft by step-pulleys. Three or more speeds may be obtained as required. It is not advisable to fix the countershaft directly above the machine owing to the trouble caused by oil and dirt dropping on to the Platen.

Before starting the motor or shafting it is advisable to make sure that the clutch is disconnected, i. e. the flywheel must turn freely. The flywheel must only be turned in the direction as indicated by the arrow on the flywheel.




**Oiling of the Machine.** The machine should be oiled regularly. All parts requiring regular lubrication are recognisable by oil cups or red-bordered oil holes. Use the best machine oil and grease exclusively. The flywheel main bearing 0401 is self-lubricating. It should be filled until the oil shows at the oil-gauge 0446.

The oil reservoirs "A" below the vibrator on the main frame, and the oil reservoirs B, C, D, E inside the frame on the toggle lever and on the upper part of the impression rod, must be filled with oil at regular intervals. Replace the oil wicks used on the oil containers about every 6 months.


The case 1501 containing the Maltese Cross 1503 and the worm wheels 1509 and 1510, must be filled with oil until it shows at the hole on the bottom of the case. The air pump should be oiled frequently and freely, and especially when the machine is first installed.

Runners and runner tracks for the roller carriage must be kept free of grease in order to avoid any skidding of the rollers.

### CROSS SECTION




### LONGITUDINAL SECTION



The Inking Apparatus consists of a large and small inking cylinder with reciprocating movement, a distributing roller with steel rider roller arranged above it, two forme rollers, vibrator and ductor roller with ink fountain.


After inserting the forme rollers make sure that the shaft ends on the left roller bearing are secured by the catch provided for this. This must not be overlooked, otherwise the rollers are liable to jump from their bearings when the machine is running at high speed.

The roller carriage is driven from the main gear wheel by means of connecting rod 0701. It should be observed that the eccentric bolt 0702 is correctly replaced and securely locked by means of the set screw 0714, should it have been loosened.



Rear of the Inking Apparatus


- 0702
- 0714
- 0701



Front of the Inking Apparatus


The Ink Duct is fitted with a flexible American steel knife, which can be adjusted by screws 0824 in the usual way.

For convenient cleaning of the ink duct the ink knife can be removed. After loosening the two hexagon nuts by means of a spanner the knife can be easily drawn out.



Ink Duct Removing of the Ink Knife


The Setting of the Distributing Rollers. Two tommy bars are supplied with each machine for this purpose. The roller bearings on each side of the inking apparatus are provided with screws which may be easily adjusted with the tommy bars so that the composition roller only presses lightly upon the inking cylinders. The small distributing cylinder on the top of the composition roller should be set in the same way, and should just "kiss" the roller beneath it. After setting be careful to lock the screws by the nuts provided for this purpose. When adjusted in this way the life of the rollers is considerably lengthened, as "flats" will not appear if the setting is properly carried out. The careless adjusting of the rollers may also cause the distributors to run hot, especially during the warm weather or when using "tacky" inks.



Setting of the  
Distributing Rollers

Setting the Roller Tracks for the Forme Rollers. To make this adjustment the cheese-headed screws F 6 should be loosened with the screw-driver and the knurled eccentric nuts 0633 should be turned in the direction the runner tracks are to be set. When the tracks are equally adjusted in all four positions, the cheese-headed screws should be re-tightened. The fly-wheel has been provided with a hole, in order that the bottom screw on the fly-wheel side of the machine may be easily reached.


The disadvantages of incorrectly setting the runner tracks are known to every printer. If the tracks are set too far back, the composition rollers will become cut, and an uneven inking and a smeared result will be obtained. If set too far forward, the inking will probably be much lighter on one side of the impression than on the other, and will be generally inefficient. With the correct adjustment of the runner tracks the inking will be perfect.



Setting of the  
Roller Tracks

The Setting of the Ductor Movement is easily done by turning an eccentric cam. To facilitate this adjustment a handle has been provided, and the ductor movement can either be discontinued altogether, or may be set for operating from one to seven teeth after each impression. Each tooth corresponds with an ink pick-up on the vibrator roller approximately  $\frac{1}{4}$  of an inch, and therefore the maximum ink pick-up is  $1\frac{3}{4}$  inches.


The setting of the ductor movement may be carried out while the machine is working, without the use of any tools, as the eccentric cam stops at each movement of the pawl over the teeth.



Setting the Ductor Movement

The Chase. The right hand inner edge of the chase provides the lay of the sheet, and the forme should therefore be locked up to this side. Should the margin be more than  $\frac{1}{5}$ " more space must be left between the type and the chase accordingly. The type matter should be placed horizontally in the middle of the chase. The scale which is marked on the chase corresponds with the scale marked on the base of the feed and delivery tables, and this enables the type and the pile of paper to be placed in the correct positions without any difficulty.

The Placing of the forme in the Machine. This is performed in exactly the same way as on an ordinary platen, by sliding the chase downwards vertically between the runner tracks with the upper edge slightly inclined forward until it rests upon the chase holders 0104. Press the chase against the projecting chase catch 0106 until it passes the lip of the chase and automatically locks under the catch spring. When lifting the forme out, press the chase catch upwards and lift the forme out vertically. Both actions are done most conveniently when the platen is in the laying-on position with the forme rollers in the bottom position.




Placing the Forme in the Machine

The Tympan Packing should be of 1 mm. ( $1/25''$ ) for printing ordinary letter paper, and proportionately thinner for heavier papers.

The Make-ready is carried out in the same way as on an ordinary platen. In view of the fact that the grippers pass over the make-ready, this must not be done on the top sheet, but underneath. The grippers pass over the surface of a normal packing leaving a distance of no more than  $1/2$  mm. ( $1/50''$ ), and should the packing be too bulky the make-ready may interfere with the movement of the grippers, or the tympan packing become injured.

The Frisket Fingers are adjusted as on ordinary platens. Usually, however, it is only necessary to use friskets for tabular work or jobs in which the paper and ink have a tendency to adhere together. The frisket fingers must be set to avoid the type and the forme.

The Tympan  
Packing and the  
Make-ready




The Regulation of the Impression can be effected while the machine is running. To increase the impression loosen the locking nut 1702 with the right hand by turning it to the left, and at the same time holding sleeve 1703 in position with the left hand. Then turn the sleeve 1703 to the right until the impression is of the required strength and re-tighten the locking nut 1702. To reduce the impression the sleeve 1703 should be turned in the opposite way.

The impression may be thrown off or put on while the machine is running. To put the impression on pull out the handle 1701 until it drops into its rest on the frame of the machine. To throw the impression off lift the handle 1701 and push it inward.

When running up ink or preparing the machine for printing, the impression should be thrown off, in order to avoid printing on the tympan.

Special care should be taken when about to start printing a fresh forme. The impression should first be set lightly, in order to prevent any overloading of the mechanism. After taking a pull the impression can be increased to the required strength.


Regulation  
of the  
Impression



The Starting or Stopping of the Machine is effected by moving the lever 1907. To start the machine put in the clutch by moving the lever to the left, until the stop on the lever rests against the bracket stop for the automatic throw-off 1647. Hold in the right hand the thrown off impression lever, and directly the first sheet is passed to the grippers, pull out the impression lever and thus put on the impression. The machine will automatically stop when the paper pile is used up or should the suckers fail to pick the sheet up for any reason.

In order to avoid constant stoppages while running up ink, the automatic throw off may be put out of action by pulling out the knurled collar 1642 and giving it a quarter turn to the right and releasing it. Do not omit to replace this collar before commencing to print, as if this is not done the machine would not stop automatically in the event of a sheet not feeding and result in a print on the packing.

To stop the machine by hand give the lever 1907 a slight right-hand turn, and by means of a spring the lever will then be pulled to the right and the machine will stop.



1642 1647


Starting  
and Stopping  
the Machine

The Automatic Throw-off. When altering the stroke of the pump, or when printing small sizes or tissue paper the automatic throw-off sometimes fails to operate, although the sheet has not been picked up. In this case screw inwards knurled screw 1650 in nozzle 1639 until the automatic throw-off works properly.

Should it happen that the machine keeps on stopping automatically, although a sheet has been picked up, screw knurled screw 1650 outwards.

The knurled screw serves to increase or lessen the tension of the spring in the air cylinder. After adjusting care must be taken to secure the knurled screw by the clamping nut 1664.

The automatic throw-off also may fail to operate after the machine has been running for some time, and this is usually due to the paper dust from the feed table accumulating inside the suction nozzle. This hampers the movement of the small plunger. The simplest way to overcome this trouble is by cleaning same. Unscrew the two screws which connect the suction nozzle 1639 with the lever embodying automatic throw-off and then the plunger can be removed, and cleaning is easy. When refitting be sure to fit the spring plate and spring. The trouble will be overcome when the spring has been regulated correctly.



1639 1664 1650

Setting of the  
Automatic  
Throw-off


Preparation of the Machine for Printing. To stack the paper on the Feed Table first disengage the connection between the Feed and Delivery Tables by loosening the Clutch on the Table Base 1001 below the Delivery Table 1010 by turning the handwheel 1123 towards you. This enables the Feed and Delivery Tables to work independently. Lift with your left forefinger the checking Pawls 1013 and 1018 and with your left thumb lift the Pawl 1103, thus leaving the teeth of Ratchet Wheel 1101 free. The Feed Table may then be lowered by turning the Ratchet Wheel 1101 with your right hand.

The Suckers should be in their lowest position before placing the pile on the Feed Table. The top sheet of the pile should not actually reach the Suckers themselves, but should be approximately 1/16th of an inch lower. The Delivery Table can then be lifted to its required position to receive the printed sheets and reconnected to the Feed Table by turning the handwheel 1123 to the right. The Lay Standards on both Feed and Delivery Tables are adjustable to the size of paper being printed by sliding into the T shaped slots.


A few proofs should be taken to see if the position of the forme corresponds with that of the paper, and if this is not the case make the necessary adjustment by shifting the pile of paper on the Feed Table to agree with the position of the forme, or if necessary, re-set the type matter in the Chase. The paper should be well fanned out to separate the sheets and ensure consistent feeding of one sheet only at a time. This is very important, as it will be found that paper often sticks together if cut by a blunt Guillotine knife.

Suckers which do not cover the paper and are, therefore, not required should be turned off. The sucker is closed when the head of the tap plug is at right angles with the Sucker, and open when the plug head is in the direction of the air suction.

Printing two-up and Printing Envelopes. Extra Accessories are not required for this. When printing two sheets at a time (two-up) use the centre standards 1004 and 1020, which serve as partition for the two piles. When printing envelopes and paper bags care should be taken that they do not adhere together or get entangled by the flaps.




Printing two-up  
Printing Envelopes



Front View while  
printing two-up

The Sheet Steadier prevents the sheets from leaving the front lay standard from the effect of the blower, springs keeping the top sheets against the front lay gauge.

When preparing the machine for printing loosen knurled screws 2210 and turn the two springs 2203 upwards. When the machine is ready, turn the springs down and place the sheet steadier bar 2212 in position, so that the springs 2203 are slightly inclined towards the machine and lightly touch the back edge of the top sheets. Then tighten screws 2210. The screws 2209 allow the springs to be adjusted accurately.




Adjusting of the Sheet Steadier

The Blower is fixed on the back of the front lay gauge 1201 and should be so adjusted that the upper holes blow over the paper pile, and the lower holes between the first and following sheets. For adjustment unscrew the knurled nuts 1619 and move the blower 1202 up or down as required. The blower should operate in such a way that it blows the top sheet towards the sucker bar and the air stream then separates the top sheet from the pile. The quantity of blowing air can be regulated on the air pump by means of the two-way tap. The top pipe on the two-way tap leads to the delivery and the bottom pipe to the blower on the feed. The two-way tap supplies a greater quantity of air in the direction in which the tap plug points. In addition to this an air regulating screw is fitted to the cover of the air pump through which the superfluous air can escape.

The Tripping Studs 1205 are riveted to tripping blades 1204, which are fixed on spindle 1206 and at the back of the front lay gauge 1201.

The function of the tripping studs is to separate the sheets and to prevent the taking of sheets adhering together. The studs must be adjusted to the kind of paper in use, by means of the knurled screws 1211, below the blower, shifting the balance lever 1207.


For thin papers the tripping studs should fully protrude from the front lay gauge. For cardboard they must be standing back otherwise they might push the stiff board from the suckers.



Setting of the Blower and the Tripping Studs

Tilting of the Sucker Bar is another means of separating the sheets. For thinner papers the angle of the sucker bar must be greater than is necessary for heavy paper or cardboard. The adjustment is made as follows: loosen the two knurled nuts 1619 (see illustration) and by turning the top or bottom one, the tilting rod 1613 may be adjusted. By adjusting the rocking lever 1604 and connecting rod 1611 the sucker bar can be set.

When taking the sheet the sucker bar takes the tilting position as adjusted, whereas the position of the sucker bar when passing the sheet to the grippers remains always the same. To ensure the correct adjusting for different papers please note table on page 37. After the adjustment tighten the knurled nuts. The tilting position of the suckers is of great importance to the correct working and should, therefore, always be carefully observed.




Tilting of the Sucker Bar

The Lifting of the Feed Table is operated by the gauge bar 1632, the paper height lever 1605, adjustment rod 1615, pawl 1103 and ratchet wheel 1101. The pawl 1103 fitted to the lever 1102 receives a periodical movement from an adjustable lever fitted to the driving gear through the connecting rod 1112. Adjustment is effected by loosening adjusting nuts 1664 and turning rod 1615. When the pile does not feed high enough the rod 1615 should be shortened which will then allow the pile to feed to the correct height, when the pile feeds too high the rod should be lengthened, which will automatically bring the pile down to the correct height. The nuts 1664 must be retightened after adjustment.

The correct setting of the feed table movement is very essential for continuous printing. In the case of tissue paper the distance between the top sheet of the pile and the suckers should be approximately  $\frac{1}{12}$ ". Cardboard should just touch the suckers; if the distance is too wide the cardboard would not be lifted owing to its weight. This distance will be automatically controlled by the rod according to how it is set.


As the feed table lifts the delivery table lowers automatically at the same speed.



Setting of the Paper Movement

1605  
1615  
1103  
1101


The Valve on the Sucker Bar. The suction air is normally regulated by increasing or decreasing the stroke of the air pump. A special valve has been fitted on the end of the sucker bar for use when printing very thin and porous papers, and through which the air passes and the vacuum becomes reduced and not more than one sheet is taken. It is only necessary to use this valve if the suction air is too strong even when the smallest stroke of the pump is in use. The valve screw must be secured by the locking nut after adjustment.



Valve on the Sucker Bar


The Air Pump operates the suction air and the blowing air. The bottom nozzle 1807 of the air pump 1801 is connected by a rubber tube with the suction nozzle for the automatic throw-off. The blowing air is formed above the piston and is separated by the two-way tap.

The stroke of the pump can be adjusted according to the required quantity of suction and blowing air, by loosening the hexagon nut and moving the crank pin 1808. Tighten the nut after adjustment. The taps on the pump cylinder are for the purpose of regulating the supply of air to the blowers on feed and delivery tables.



Setting of the Stroke on the Air Pump


The Clack Valve on the Air Pump. The purpose of this valve is to stop the vacuum in the sucker bar tube immediately the gripper has closed and taken the sheet. If the valve opens too early the lifted sheet will not be passed properly to the grippers; if it opens too late the suckers might probably pull the sheet off the grippers, and in both cases register will be affected. The correct adjustment is carried out as follows: The clack 1824 strikes the screw S 8 and is thus opened. After loosening the nut with a spanner this screw can be adjusted. The further the screw is screwed into the stop, the earlier the valve opens. This adjustment may be necessary when setting a longer stroke.



Clack Valve on  
the Air Pump

1824 S 8


The Setting of the Delivery Blower is very essential for a perfect piling up of the printed sheets and is set in the following method: The direction of the air stream can be altered as desired by turning the blower tube 2111 after loosening the fixing nut 2112. The pin on top of the bar shows the direction of the air stream.



Setting of the  
Delivery Blower

The blower tube can also be set higher or lower; moved forward or backward after the clamping screw or the nut has been loosened with a spanner.


If the quantity of blowing air over the delivery table is set properly the speed of the machine can very often be increased and the delivery will be equally good as when the machine is run at a lower speed. This adjustment is very important when printing thin papers. The air stream prevents the corners of the sheets from curling and correctly places the sheets on the pile. The air circulation also facilitates the drying of the prints. The force of air stream can be regulated by the two-way tap on the air pump or by setting the stroke of the pump.



Raising and Lowering of the Blower Tube


The Delivery Appliance for Small Sizes is of great advantage when printing small size jobs, and allows a better delivery. An adjustable rod 2302 carrying four adjustable delivery slides 2303 is fitted to the left hand delivery lay standard. Knurled clamping screws 2305 hold the delivery slides and the clamping pieces 2301 to the rod. The delivery slides are set so that the sheet slides towards the front lay standard after the gripper has opened.

In many cases two delivery slides are quite sufficient, but when printing small jobs or two-up the use of four delivery slides is advisable.



Delivery Appliance for Small Sizes

The Re-setting of the Friction Clutch may be necessary after the machine has been running for some time. This is necessary if the flywheel fails to move the machine while on impression. The re-setting is a simple operation and should be carried out as follows: With the screw driver in one hand, hold the clutch adjusting screw D 13 so that it does not move when loosening the nut D 14 with the spanner. Then move the clutch adjusting screw half a turn to the right and retighten the nut. The opposite screw should be treated in the same way, and this slight adjustment will be quite sufficient in most cases.




Re-setting of the Friction Clutch

## Extra Appliances

Rubber Sucker Bars can be supplied to order. Rubber Sucker bars are used when printing heavy cardboard or wavy papers, pasted bags, etc. The sucker bar can be easily removed in the following way:

After loosening the hexagon screw Q 4 on the sucker bar bracket 1606 the ordinary sucker bar can be easily removed from the sucker bar bracket. The rubber sucker bar is placed in position in such a way that the small pin on the sucker bar fits in the slot of the sucker bar bracket. By means of this the sucker bar is fixed in the correct position. Afterwards retighten the hexagon screw.


Each sucker can be turned off by knurled clamping screws. The rubber caps fitted to the aluminium suckers can be easily exchanged and new caps can be supplied at any time.



Rubber Sucker Bar

The Sheet Counter. A five figure sheet counter is supplied. This is fitted on the front of the machine and is operated from the platen by special fittings. The sheet counter only records the printed sheets. When the impression is thrown off the counter does not register.

The Lay Standard for very small sizes. This is to be fixed in such a way that the centre portion fits into the slot of the delivery table. This Lay Standard is generally used for very small and short sizes or thin papers which would not pile up properly without this device.



Lay Standard

Lay Standard for very small sizes


Sheet Counter

Table for Adjusting the Most Important Parts when Working:

Name of the Adjustable part	Tissue Paper	Ordinary Letter Paper	Cardboard for Post Cards
<i>Paper Table</i> Turn ratchet wheel 1101 by hand	Top sheet about $\frac{1}{12}$ " from lower edge of suckers	Top sheet about $\frac{1}{16}$ " from lower edge of suckers	Top sheet just touching lower edge of suckers
<i>Blower</i> Adjust air regulating screw 1812 or the stroke on the pump (see page 25)	Slight air between sheets and plenty over sheets on delivery table	Half air between sheets and half over paper on delivery table	All air between cards on feed table
<i>Tripping Studs</i> Adjust knurled screws 1620 (see page 25)	Coming out fully, springs slightly touch front paper stop	About $\frac{1}{8}$ " out. Springs quite free	Entirely receding, springs rest against blower
<i>Suckers</i> Adjust rocking lever 1604 (see page 26)	Lower edge of suckers to be turned $30^\circ$ backwards against paper edge	Lower edge of suckers to be turned $15^\circ$ backwards against paper edge	Lower edge of suckers to be parallel to paper edge
<i>Paper Feed</i> Adjust gauge rod 1615 (see page 27)	One stroke for every 15th to 20th sheet	One stroke for every 7th to 10th sheet	One stroke for every 3rd or 4th sheet
<i>Automatic Throw-off</i> Adjust knurled screw 1650 in air cylinder 1609 (see page 21)	Spring in the air cylinder to be but slightly tightened	Spring in the air cylinder to be moderately tightened	Spring in the air cylinder to be fully tightened
<i>Output</i> Regulate starter of electric motor	1000 to 2000 prints per hour	3000 prints per hour	2500 to 3000 prints per hour


# I N D E X   O F   G R O U P S

Table	Description	Page
A	Frame . . . . .	41
B	Platen . . . . .	43
C	Toggles and Connecting Rod . . . . .	45
D	Flywheel, Driving Shaft and Clutch . . . . .	47
E	Crank Shaft and Cams . . . . .	49
F	Inking Apparatus . . . . .	51
G	Roller Carriage . . . . .	53
H	Ink Fountain . . . . .	55
I	Rollers . . . . .	57
K	Paper Table . . . . .	59
L	Moving Gear for Paper Table . . . . .	61
M	Front Lay Gauge and Blower . . . . .	63
N	Gripper . . . . .	65
O	Gripper Mechanism . . . . .	67
P	Gripper Movement . . . . .	69
Q	Sucker Bar and Guide . . . . .	71
R	Impression Throw-off Lever . . . . .	73
S	Air Pump . . . . .	75
T	Clutch Lever . . . . .	77
U	Frisket Bar . . . . .	79
V	Guards . . . . .	81
W	Sheet Steadier . . . . .	83
X	Delivery Slides for small Sizes . . . . .	85
Y	Tools . . . . .	87
Z	Sheet Counter . . . . .	89




## T A B L E A. F R A M E

Part No.	Description	Quantity	Part No.	Description	Quantity
0101	Frame	1	0146	Adjusting Collar for 0145	1
0102	Bush for Driving Shaft	1	0147	Trunnion for 0142	1
0103	Chase with Centre-piece	1	A 1	Collar for Motor Bracket Spindle, N 108, 20×13 mm	2
0104	Bolts for holding Chase	2	A 2	Washer for A 3, N 65/1 10,3 mm	2
0105	Bracket for Chase Catch	1	A 3	Hexagon Nut for 0126 and A13, N 61/1, 10 mm	3
0106	Chase Catch	1	A 4	Hexagon Screw for 0104, N 46/1, 10×40 mm	2
0107	Pin for Chase Catch	1	A 5	Cheese-headed screw for Part 0105, N 48/1, 8×22 mm	2
0108	Inspection Plate	1	A 6	Square-headed Screw for fixing 0124 and 1928, N 107, 8×30 mm	3
0109	Spring for Chase Catch	1	A 7	Screw for fixing 0111 and 0128, N 48/1, 5×12 mm	6
0110	Lid for Oil Container	2	A 8	Screw for fixing Clips 0115, N 48/1, 6×10 mm	2
0111	Circular Inspection Plates	2	A 9	Lubricator, No. 1 size, N 73	2
0112	Packing Rings for Pipes in Oil Container	6	A 10	Split Pin for 0126, N 75, 3×25 mm	1
0114	Tube for Suction Air	1	A 12	Pin for fixing Inspection Plate, N 71, 8×55 mm	1
0115	Clips for Air Tubes	2	A 13	Hexagon Screw for 0139, N 81, 10×45 mm	1
0116	Platen Shaft	1	A 14	Grub Screw for A 1, N 53, 8×12 mm	2
0117	Short Oil Pipe in Oil Container	2	A 15	Hexagon Nut for 0138, N 61/1, 16 mm	1
0118	Oil Pipe for Driving Shaft	1	A 16	Guide Pin for Chase, N 71, 8×20 mm	1
0119	Oil Pipe for Crank Shaft, Fly-wheel Side	1	A 17	Hexagon Nut for 0139, N 62, 12×9 mm	1
0120	Oil Pipe for Platen Shaft, Fly-wheel Side	1	A 18	Packing Washer for 0138, N 65/1, 16,5 mm	1
0121	Oil Pipe for Platen Shaft, Cam Side	1	A 19	Grub Screw for A 23, N 53, 8×16 mm	2
0122	Pin for pushing out Chase	1	A 20	Key for fitting 0141 to 0116, N 113/1, 8×12×25 mm	1
0123	Motor Bracket, left	1	A 21	Taper Pin for 0142, N 72, 4×45 mm	1
0124	Spindle for Motor Bracket	1	A 22	Taper Pin for 0141, N 72, 8×80 mm	1
0125	Pin for locating Guard 2108	2	A 23	Collar for 0138, N 108, 24×14 mm	2
0126	Bar for Belt Adjustment	1	0827	Spring Washer for 0108	2
0128	Centre Piece	1			
0131	Pivot Stud	1			
0132	Bush for Platen Shaft	2			
0133	Spring for Belt Adjusting Bar	1			
0134	Bush for Crank Shaft	1			
0135	Chase	1			
0136	Motor Bracket, right	1			
0138	Shouldered Pin carrying 1801	1			
0139	Stop carrying Regulating Screw S 8	1			
0140	Oil Wick with Wire	6			
0141	Lever for Platen Balancing Spring	1			
0142	End Piece for 0143	1			
0143	Spindle carrying Spring 0145	1			
0144	Stop for Spring 0145	1			
0145	Platen Balancing Spring	1			



T A B L E B. P L A T E N

Part No.	Description	Quantity	Part No.	Description	Quantity
0201	Swinging Platen	1	B 3	Screw for Tympan Clip, N 48/1,	
0207/0220	Tympan Bar	2		8×10 mm	2
0208	Tympan Bar	1	B 4	Metal Name Plate, N 122/2	1
0209	Clip for Tympan Bar	2	B 5	Copper Rivets for fixing above,	
0215	Toggle Pin in Platen	1		N 78, 3×6 mm	2
0216	Hexagon Screw for fixing Platen Shaft	1	B 6	Counter-sunk Screw for 0221,	
0218	Clip for Tympan Bar	4		N 50/1, 6×20 mm	2
0221	Stopping Washer for 0215	2		Cheese-headed Screw for 0218,	
B 2	Hexagon Screw for 0215, N 81,	1		N 48/1, 5×12 mm	4
	10×42 mm				



T A B L E C. T O G G L E S

Part No.	Description	Quantity	Part No.	Description	Quantity
0301	Front Toggle	1	0314	Oil Pipe for 0304	1
0302	Rear Toggle	1	0315	Distance Washer	2
0303	Toggle Bearing	1	0140	Oil Wick	6
0304	Connecting Rod	1	0215	Pin coupling Connecting Rod to Toggles	1
0305	Eccentric for Impression Regulation	1	C 1	Hexagon Screw for fixing Toggle Pins, N 81, 10×20 mm	2
0306	Split Big End Bush for Connecting Rod	2	C 2	Hexagon Nut for 0304, N 62, 12×9 mm	4
0307	Pin for fixing Rear Toggle to Bearing	1	C 3	Stud for 0304, N 52, 12×55 mm	2
0308	Bush for Front Toggle	1	C 4	Hexagon Screw for 0303, N 47, 16×35 mm	1
0309	Bush for 0301	2	C 5	Hexagon Screw for fixing 0215 and 0307, N 81, 8×20 mm	4
0310	Distance Washer	1	C 6	Pin for fixing 0306, N 71, 6×18 mm	1
0311	Oil Pipe for 0301, 0303 and 0304	5			
0312	Washer on C 4 fixing 0303	1			
0313	Bush for 0304	1			





TABLE D. FLYWHEEL AND DRIVING SHAFT

Part No.	Description	Quantity	Part No.	Description	Quantity
0401	Bracket for Driving Shaft	1	0442	Eccentric Pin	1
0402	Clutch Operating Cone	1	0443	Hardened Tongues for Clutch	2
0403	Clutch Ring	1	0445	Plate for Coupling Lever	1
0404	Flywheel	1	0446	Oil Lever Pipe	1
0405	Clutch Lever, L. H.	1	0140	Oil Wick	1
0406	Screwed Locking Ring for Flywheel	1	1407	Plunger holding spring 1416	1
0407	Locking Ring for Ball Bearing in Flywheel	2	1416	Compression Spring	1
0408	Distance Piece between Ball Bearing	1	D 1	Screw for fixing Cover 0435, N 48/1, 8×40 mm	2
0409	Bush carrying Ball Bearing in Flywheel	1	D 2	Pin for 0437 and 0427, N 71, 6×32 mm	1
0410	Driving Shaft	1	D 4	Lubricator No. 1, N 73	3
0411	Ball Bearing No. 211, L	2	D 5	Taper Pin for fixing 0420, N 72, 5×60 mm	1
0414	Oil Felt	2	D 6	Pin for 0401, N 71, 8×30 mm	1
0417	Cover for Oil Container	2	D 7	Lubricating Ring for Main Shaft, N 95, 55 mm	1
0420	End Collar for Shaft	1	D 8	Key for Main Shaft, N 113, 10×8×45 mm	1
0421	Pin joining 0437 to 0427	1	D 10	Screw for fixing 0443, N 48/1, 6×10 mm	2
0424	Eccentric Safety Catch	1	D 11	Square-headed Screw for fixing Pin 0438, N 107, 8×25 mm	1
0426	Locking Disc for same	1	D 12	Hexagon Screw for fixing 0442 and 0439, N 46/1, 10×35 mm	2
0427	Top Portion of Lever 0437	1	D 13	Clutch Adjusting Screw, N 111, 10×40 mm	2
0428	Chain for Oil Cover	2	D 14	Hexagon Nut for same, N 62, 10×7 mm	2
0431	Slotted Bush for Bracket No. 0401	1	D 15	Pin for 0424, N 71, 5×32 mm	1
0433	Clutch Lever, R. H.	1	D 16	Screw for 0428, N 48/1, 4×6 mm	2
0434	Pin for 0424	1	D 17	Grub Screw for fixing 0434, N 53, 8×16 mm	2
0435	Clutch Cap	1	D 18	Hexagon Screw for Bracket 0401 and 0441, N 47, 12×40 mm	5
0436	Inverted Brake Cone	1			
0437	Lever for Sucker Bar Movement	1			
0438	Pin for Centre Bearing of Lever 0437	1			
0439	Pin for 0437 carrying Roller 0440	1			
0440	Roller for Sucker Bar Movement Lever	1			
0441	Balance Weight for Sucker Bar Movement Lever	1			



T A B L E E. C R A N K S H A F T

Part No.	Description	Quantity	Part No.	Description	Quantity
0501	Crank Shaft	1	E 3	Counter-sunk screw for fixing	
0502	Main Gear Wheel	1		0502, N 50/2, 12×25 mm	1
0503	Pin in 0502 carrying 0509 and 0701	1	E 4	Hexagon Screw for fixing 0505 to 0504, N 46/1, 10×30 mm	2
0504	Internal Cam operating Propeller Motion	1	E 5	Taper Pin fixing 0509 to 0503, N 72, 4×45 mm	1
0505	Control Cam for same	1	E 6	Washer for 0510, N 65/1, 10,3 mm	1
0506	Hardened Pin for Rollers 0440	2	E 7	Split Pin for 0510, N75, 2×20mm	1
0507	Spring Retaining Ring for 0506	2	E 8	Hexagon Nut for 0510, N 62, 10×7 mm	1
0508	Washer for fixing 0502 to 0501	1	E 9	Hexagon Nut for 0511, N 62, 8×6 mm	1
0509	Lever carrying Eccentric Pin 0510	1	E 10	Guide Pin on 0505, N 71, 5×24 mm	1
0510	Eccentric Pin	1	E 11	Rivet on 0509, N 77/2, 3×20 mm	1
0511	Adjusting Screw for 0509	1	E 12	Cheese-headed Screw N 48/2, 12×12 mm	1
0512	Distance Washer	1	E 13	Taper Pin for 0513, N 72, 6,5×60 mm	2
0513	Lever for Pump Drive	1			
0440	Roller for Pin 0506	2			
E 1	Key for Cam 0504, N 113/1, 8×10×50 mm	1			
E 2	Key for Main Gear 0502, N 112/2, 8×12×45 mm	1			




TABLE F. INKING APPARATUS

Part No.	Description	Quantity	Part No.	Description	Quantity
0601	Side Frame, Flywheel Side	1	0641	Flat Spring for End of Roller Track	2
0602	Side Frame, Pump Side	1	0642	Bearing for small distributing cylinder	2
0603	Inking Cylinder	1	0643	Guide block connecting 0639 with 0923	1
0604	Roller Track, Flywheel Side	1	0644	Bearing Bolt for carrying 0639	1
0605	Roller Track, Pump Side	1	0645	Bolt connecting 0828 with 0639	1
0606	Gear Wheel for Inking Cylinder, 48 Teeth	1	0647	Counter-sunk Screw for fixing Spring 0641	4
0607	Big Intermediate Gear for Inking Cylinder, 60 Teeth	1	0109	Compression Spring for Checking Plunger 0619	2
0608	Small Intermediate Gear for Inking Cylinder, 36 Teeth	1	F 1	Taper Pin for 0617, N 72, 4x36 mm	3
0610	Journalled Pin for 0608	1	F 2	Collar on 0612, N 108, 20x13 mm	1
0611	Pin with Shoulder for 0606	1	F 3	Grub Screw for F 2, N 53, 8x8 mm	1
0612	Shaft for Inking Cylinder	1	F 4	Cheese-headed Screw for 0612, N 48/1, 8x12 mm	2
0613	Circular Nut for Part F 13	4	F 5	Washer for same, N 65/1, 8,3 mm	1
0616	Vibrator Roller Spindle	1	F 6	Cheese-headed Screw for 0601, 0602 and 0604/05, N 48/1, 10x28 mm	8
0617	Lever for Vibrator Roller, Flywheel Side	1	F 7	Cheese-headed Screw for 0607, N 48/1, 8x22 mm	3
0618	Lever for Vibrator Roller, Pump Side	1	F 9	Lubricator for 0601/02, N 73, No. 1	5
0619	Checking Plunger for Vibrator	1	F 11	Taper Pin for 0628, N 72, 4x45 mm	2
0620	Checking Lever for Vibrator	1	F 12	Dowel Pin for 0602, N 72, 5x50 mm	2
0622	Safety Catch for 0617	1	F 13	Screw with Tommy Holes for 0629, BN 82, 6x16 mm	4
0623	Pin for Spring for 0617	1	F 14	Distance Washer for 0627, N 65/1, 10,3 mm	2
0624	Knob for 0622	1	F 15	Taper Pin for 0620, N 72, 4x28 mm	1
0625	End Plate for Inking Cylinder, Flywheel Side	1	F 16	Hexagon Screw for 0618, N 46/1, 8x30 mm	1
0626	End Plate for Inking Cylinder, Pump Side	1	F 17	Hexagon Nut for 0645, N 62, 8x6 mm	1
0627	Crescent for reciprocating Inking Cylinder	1	F 18	Taper Pin, N 72, 2,5x22 mm	1
0628	Track for Crescent	1			
0629	Bearing for Distributing Roller	2			
0630	Pin for 0617	1			
0631	Spring for 0623	1			
0632	Washer for 0633	4			
0633	Eccentric for Adjusting Roller Track	4			
0634	Bush for 0608	1			
0636	Bush for 0625 and 0626	2			
0637	Bush for 0606	1			
0639	Angle Lever for Reciprocating Motion	1			
0640	Bush for 0601 and 0602	2			





TABLE G. ROLLER CARRIAGE

Part No.	Description	Quantity	Part No.	Description	Quantity
0701	Connecting Link for Roller Carriage	1	0714	Hexagon Screw for fixing 0702	1
0702	Eccentric Bolt for 0713	1	0721	Bush for 0701	2
0703	Journal Box for Inking Rollers, Flywheel Side	1	0726	Holder for Journal Box, Pump Side	1
0704	Journal Box for Inking Rollers, Pump Side	1	1114	Stud with Head connecting 0808 with 0712	1
0705	Holder for Journal Box, Flywheel Side	1	0622	Safety Catch for 0703	2
0706	Guide Block for Spring Rod	2	0623	Pin for Spring 0631	2
0708	Roller Carriage Spindle	2	0624	Knob for 0622	2
0709	Spring for Roller Carriage Spindle	2	0631	Spring for 0623	2
0710	Bolt with Head for Journal Box	2	G 1	Hexagon Screw for 0712 and 0713, N 47, 12×40 mm	2
0711	Shaft for Roller Carriage Arms	1	G 5	Taper Pin N 72, 2,5×24 mm	1
0712	Roller Carriage Arm, Pump Side	1	G 6	Taper Pin N 72, 3×28 mm	2
0713	Roller Carriage Arm, Flywheel Side	1	G 7	Taper Pin N 72, 4×28 mm	2
			G 8	Taper Pin N 72, 4×36 mm	2
			G 10	Oil Cap for 0701, N 73	2
			G 12	Grub Screw N 53, 3×8 mm	2




T A B L E H. I N K F O U N T A I N

Part No.	Description	Quantity	Part No.	Description	Quantity
0801	Ductor Roller	1	0831	Compression Spring (similar to 1826)	1
0805	Ratchet Wheel for Ductor Roller	1	0832	Plunger for 0829	1
0806	Lever for Ductor Roller Movement	1	0834	Hand Wheel for Ductor Roller	1
0807	Pawl for Ratchet Wheel	1	0645	Stud connecting 0828 with 0806	1
0808	Long Link for Ductor Roller Movement	1	1114	Stud connecting 0808 with 0806	1
0811	Central Piece of Ink Duct	1	H 1	Cheese-headed Screw for fixing 0812 and 0813, N 48/1, 8×18 mm	6
0812	End Plate for Ink Duct, Flywheel Side	1	H 2	Taper Pin for fixing 0826, N 72, 2,5×22 mm	2
0813	End Plate for Ink Duct, Pump Side	1	H 3	Washer for H 4, N 65/1, 6,2 mm	2
0815	Lid for Ink Duct	1	H 4	Stud for Knife 0817, N 51, 6×18 mm	2
0817	Ink Knife, complete	1	H 5	Cheese-headed Screw for fixing Ink Duct to Frame, N 48/1, 10×28 mm	2
0819	Lead Clump, narrow	2	H 6	Washer for H 5, N 65/1, 10,3 mm	2
0823	Lead Clump, thick	2	H 8	Taper Pin for fixing 0834, N 72, 3×30 mm	1
0824	Screw for Regulating Ink Knife	10	H 9	Taper Pin for fixing 0805, N 72, 4×36 mm	1
0825	Cheese-headed Screw for fixing 0815	2	H 11	Hexagon Nut for H 4, N 61/1, 6 mm	2
0826	Shouldered Pin for attaching 0807 to 0806	1	H 12	Hexagon Nut for 0645, N 62, 8×6 mm	1
0827	Spring Washer for 0825	2	H 13	Pin N 71, 4×20 mm	1
0828	Connecting Lever for 0639 and 0806	1			
0829	Ratchet for adjusting Ink Supply	1			
0830	Lever for same	1			



T A B L E J. R O L L E R S

Part No.	Description	Quantity	Part No.	Description	Quantity
0901	Spindle for Inking and Vibrator Roller	6	0920	Base for Roller Mould	1
0906	Small Distributing Cylinder	1	0921	Tube for Roller Mould	1
0909	Distributor Roller Spindle	2	0922	Star for Roller Mould	1
0911	Runners for Inking Rollers	4	0923	Guide Ring for 0913	1
0913	Steel Reciprocating Rider	1	J 1	Taper Pin fixing 0923 to 0913, N 72, 4×36 mm	1



T A B L E K. P A P E R T A B L E

Part No.	Description	Quantity	Part No.	Description	Quantity
1001	Base for Table, Delivery Side	1	1032	Extension for Lay Standard 1009	1
1002	Base for Table, Feed Side	1	1034	Bracket for Partition Plate 1020	1
1003	Guide for Delivery Table Rack	1	1036	Delivery Slide Extension for 1007	1
1004	Partition Plate, Delivery	1	1037	Guide Pin for 1007	2
1005	Feed Table	1	1038	Spring for 1012	1
1006	Drawer for Small Tools	1	0825	Cheese-headed Screw fixing 1013 and 1018	1
1007	Lay Standard, Delivery	1	K 1	Hexagon Screw for 1002, N 46/2, 16×40 mm	4
1008	Slotted Lay Standard, Feed	1	K 2	Hexagon Screw for 1001 and 1003, N 46/1, 10×35 mm	5
1009	Lay Standard, Delivery	1	K 3	Collar for 1015, BN 103, 30×14 mm	1
1010	Delivery Table	1	K 4	Taper Pin for K 3, N 72, 6,5×55 mm	1
1011	Runner for 1006	2	K 5	Pin for fixing 1601, N 71, 8×30 mm	2
1012	Rack for Feed Table	1	K 6	Pin for 1003, N 71, 6×24 mm	1
1013	Checking Pawl for Ratchet Wheel	1	K 7	Cheese-headed Screw for fixing 1011, N 48/1, 6×10 mm	6
1014	Washer with counter-sunk hole for 1012	1	K 8	Cheese-headed Screw for fixing 1026, N 48/1, 8×15 mm	1
1015	Rack for Delivery Table	1	K 9	Flush Rivet for 1019 and 1034, N 77/1, 4×18 mm	4
1016	Slotted Lay Standard, Feed	1	K 10	Copper Rivet for fixing Scale 1025, N 78, 3×6 mm	8
1017	Knurled Nut fixing Lay Standards	7	K 11	Lubricator for 1028, N 73	2
1018	Checking Pawl for Ratchet Wheel	1	K 12	Hexagon Screw for 1208, N 47, 12×60 mm	2
1019	Bracket for Partition Plate 1004	1	K 13	Pin for 1001 and 1002, N 71, 6×16 mm	2
1020	Partition Plate, Feed	1	K 15	Washer for K 12, N 65/1, 10,3 mm	2
1021	Washer for 0825	1	K 16	Counter-sunk Screw for 1012, N 84, 8×25 mm	1
1022	Leather Collar	1			
1023	Front Lay Standard, Delivery	1			
1024	Square Headed Bolts for fixing Lay Standards	7			
1025	Scale for setting Lay Standards	2			
1026	Stop Washer attached to 1015	1			
1027	Clamping Screw for attaching 1010 to 1015	1			
1028	Oil Pipe for 1108	1			
1030	Oil Pipe for 1003	1			
1031	Extension for Lay Standard 1007	1			




TABLE L. MOVING GEAR FOR PAPER TABLE

Part No.	Description	Quantity	Part No.	Description	Quantity
1101	Ratchet Wheel	1	0826	Shouldered Pin for 1102	1
1102	Lever for Feed Table Movement	1	L 1	Taper Pin for Part 1104, N 72, 4x45 mm	1
1103	Pawl for Ratchet Wheel	1	L 2	Collar for 1115, N 108, 20x13 mm	1
1104	Bush for Pinion 1111	1	L 3	Cheese-headed Screw for fixing L 5, N 48/1, 3x10 mm	1
1105	Outer Portion of Clutch	1	L 4	Taper Pin for 1102, N 72, 2,5x22 mm	2
1106	Inner Portion for same	1	L 5	Key for Shaft 1108, N 113/1, 8x7x40 mm	1
1107	Gear Wheel	1	L 6	Hexagon Screw for 1103, N 46/1, 8x30 mm	2
1108	Shaft for Table Movement Mechanism	1	L 7	Washer for L 8, N 65/1, 8,3 mm	3
1109	Sleeve carrying 1101 and 1111	1	L 8	Hexagon Nut for L 6, N 61/1, 8 mm	2
1110	Spring for Table Clutch	1	L 9	Counter-sunk Screw for fixing 1125 to 1120, N 50/1, 6x12 mm	1
1111	Pinion for Shaft, 16 teeth	3	L 10	Grub Screw for fixing 1111 to 1105, N 54, 4x8 mm	4
1112	Connecting Rod with End Pieces operating Lever 1102	1	L 11	Flat round-headed Screw, N 131, 8x30 mm	1
1113	Stud with Head for 1102	1	L 12	Wing Nut, N 63, 8 mm	1
1114	Journalled Shaft for 1101	1	L 13	Grub Screw for L2 and 1124, N 53, 8x12 mm	2
1115	Pin with Collar carrying 1107	1			
1116	Washer for 1108	1			
1117	Hollow Shaft	1			
1118	Hexagon Nut for 1108	1			
1119	Shouldered Pin with flat Side	1			
1120	Brake Lever, complete	1			
1121	HandWheel, N 109, 14x125 mm	1			
1122	Adjusting Ring	1			
1123	Washer with countersunk Hole	1			
1124	Grub Screw for L2 and 1124, N 53, 8x12 mm	1			
1125	Washer	1			





TABLE M. FRONT LAY GAUGE AND BLOWER

Part No.	Description	Quantity	Part No.	Description	Quantity
1201	Front Lay Gauge	1	M 1	Fixing Screw for 1203, N 48/1, 6×12 mm	6
1202	Blower Head	1	M 2	Washer for 1202, N 65/1, 6,2 mm	2
1203	Clip for Tripping Blade	6	M 3	Taper Pin Fixing 1206 to 1207, N 72, 2,5×20 mm	1
1204	Tripping Blade	6	M 4	Rivet fixing 1203 to 1204, N 78, 3×8 mm	12
1205	Stud on Tripping Blade	6	M 5	Rivet fixing 1201 to 1208, N 73, 5×14 mm	4
1206	Rod for Tripping Blades	1	M 6	Cheese-headed Screw for fixing 1208, N 48/1, 8×22 mm	2
1207	Adjusting Lever for same	1			
1208	Base for Front Lay Gauge	1			
1209	Rubber Tube for Blower	1			
1211	Adjusting Screw for 1207	2			
1619	Knurled Nut for 1202	2			



T A B L E N. G R I P P E R

Part No.	Description	Quantity	Part No.	Description	Quantity
1301	Gripper carrier	1	1323	Trunnion for 1312 and 1313	2
1302	Top Lever operating Gripper Blade	2	1324	Rivet for attaching 1314 to 1302 and 1308	4
1303	Bottom Lever operating Gripper Blade	2	1326	Washer for 1321, 0,8×5,2 mm	2
1304	Top Part of Gripper (Aluminium)	2	1327	Round Rivet Nut for 1321	2
1308	Gripper Blade	2	1329	Ball Pressure Oiler	2
1309	Pin for carrying 1302 and 1303	2	N 1	Square Counter-sunk Screw for 1304, N 50/1, 6×20 mm	4
1310	Threaded Shouldered Pin carrying Roller 1311	2	N 2	Washer for same, N 65/1, 6,2 mm	4
1311	Roller for Gripper operating Lever 1303	2	N 3	Nut for N 1, N 61/1, 6 mm	4
1312	Bar carrying Spring 1313	1	N 4	Taper Pin for Big End of 1303 and 1302, N 72, 4×26 mm	4
1313	Spring for same	1	N 5	Taper Pin for Small End of 1303, N 72, 2,5×18 mm	2
1314	Rod connecting 1302 to 1308	2	N 6	Split Pin for 1312, N 75, 1,6×10 mm	2
1319	Bush in Gripper Carrier 1301	2	N 7	Nut for 1321, N 61/1, 5×5 mm	4
1321	Steel Rod with Threaded End for Gripper Hinge	2			




TABLE O. GRIPPER MECHANISM

Part No.	Description	Quantity	Part No.	Description	Quantity
1401	Gear Case	1	1436	Screw fixing 1409 to 1417	1
1402	Cover for Gear Case	1	1437	Hexagon Screw with left hand thread for fixing 1405	1
1403	Bearing carrying 1404	1	O 1	Cheese-headed Screw for 1402 and 1406, N 48/1, 8×30 mm	3
1404	Shaft	1	O 2	Lubricator, No. 1, for 1401 and 1402, N 73	2
1405	Bevel Pinion	1	O 3	Cheese-headed Screw for 1402, N 48/1, 8×60 mm	2
1406	Gripper Locking Disc	1	O 4	Dowel Pin locating 1429, N 72, 6,5×55 mm	2
1407	Plunger	1	O 5	Washer for 1437, N65/1, 8,3 mm	1
1408	Lever	1	O 6	Hexagon Nut for 1427 and 1424, N 62, 8 mm	3
1409	Connecting Piece between 1413 and 1419	1	O 7	Dowel Pin for 1406, N 71, 8×30 mm	2
1410	Bush for 1403	1	O 8	Taper Pin for 1425, N 72, 5×36 mm	1
1411	Collar for 1407	1	O 9	Hexagon Screw for fixing 1403, N 46/1, 10×65 mm	2
1412	Gripper Locking Pawl	1	O 10	Cheese-headed Screw for fixing 1401, N 48/2, 12×45 mm	1
1413	Cam operating Grippers	1	O 11	Hexagon Screw for fixing 1401, N 47, 12×35 mm	1
1414	Bevel Gear with Shaft	1	O 14	Grub Screw for fixing 1411, N 53, 6×8 mm	1
1415	Shouldered Pin with Threaded End carrying 1408	1	O 15	Hexagon Nut for fixing 1415, N 62, 10 mm	1
1416	Compression Spring for 1407	1	O 16	Cheese-headed Screw fixing 1417 and 1409, N 48/1, 4×10 mm	1
1417	Pin attaching 1409 to 1413	1	O 17	Taper Pin locating 1403, N 72, 6,5×55 mm	2
1418	Bush for 1401 and 1402	2	O 18	Hexagon Screw for 1401, N 47, 12×60 mm	1
1419	Bar operating Cam 1413	1			
1420	Washer between 1413 and 1301	1			
1421	Hexagon Screw fixing Gripper Assembly to 1414	1			
1422	Coil Spring	1			
1424	Bolt with Shoulder for 1412	1			
1425	Collar with Serrated End fixing 1405	1			
1426	Roller for 1415	2			
1427	Bolt with Shoulder for 1408	1			
1428	Packing Plate	1			
1429	Bearing carrying 1404	1			
1430	Bush for 1429	1			
1431	Safety Washer	1			
1432	Hexagon Screw fixing 1429	2			




TABLE P. GRIPPER MOVEMENT

Part No.	Description	Quantity	Part No.	Description	Quantity
1501	Bearing Case	1	1536	Spring Ring	2
1502	Cover for same	1	0440	Roller for 1512 in 1504	1
1503	Maltese Cross	1	1417	Pin coupling 1504 with 1419	1
1504	Control Lever	1	P 1	Cheese-headed Screw fixing 1502 to 1501 N 48/1, 10×28 mm	4
1505	Bush for Main Bearing in 1501	1	P 2	Pin locating 1502 to 1501, N 71, 8×28 mm	3
1506	Bush in top of Cover 1502	1	P 3	Lubricator, No. 1, N 73	4
1507	Shaft carrying 1519 and 1516	1	P 4	Cheese-headed Screw fixing 1524 to 1501, N 48/1, 5×50 mm	1
1508	Bush for 1504	1	P 5	Hexagon Screw fixing 1501 to 1511, N 47, 16×35 mm	3
1509	Worm Wheel	1	P 6	Pin locating 1501, N 71, 10×28 mm	1
1510	Worm Pinion with Shaft	1	P 8	Cheese-headed Screw fixing 1503 to 1509, N 48/1, 10×42 mm	2
1511	Shaft for 1503	1	P 9	Feather Key in 1511, N 113/1, 10×8×40 mm	1
1512	Pin for 1504 carrying 0440	1	P 11	Taper Pin for 1507, 1510 and 1516, N 72, 5×40 mm	5
1513	Bush in 1501 carrying Shaft 1511	1	P 13	Cheese-headed Screw fixing 1518, N 48/1, 4×10 mm	4
1514	Bush in 1517 for 1507	1	P 14	Hexagon Screw fixing 1517, N 46/1, 10×30 mm	1
1516	Universal Joint	1	P 15	Taper Pin locating 1503 to 1509, N 72, 6,5×45 mm	1
1517	Bearing Bracket carrying Bevel Gears	1	P 16	Grub Screw fixing 1417 to 1419	5
1518	Cap for same	1	P 17	Taper Pin, N 72, 5×36 mm	2
1519	Bevel Gear	2			
1520	Bush in 1502 carrying Shaft 1511	1			
1521	Bush in 1517 for 1510	1			
1522	Oil Pipe for Main Bearing in 1501	1			
1523	Oil Pipe for Bearing of Shaft 1511 in 1501	1			
1524	Top Cover for 1501	1			
1526	Thrust Ball Race AJ 25 between Maltese Cross and 1501	2			
1535	Oil Pipe in 1502 leading to 1512	1			




TABLE Q. SUCKER BAR AND GUIDE

Part No.	Description	Quantity	Part No.	Description	Quantity
1601	Bracket carrying Sucker Bar Movement	1	1650	Adjusting Screw for Automatic Throw-off	1
1602	Bearing Bracket attached to 1630	1	1651	Compression Spring for 1649	1
1603	Guide Block for 1630	1	1652	Washer between Spring 1624 and 1650	1
1604	Lever controlling angle of Suckers	1	1654	Flange Packing Washer between 1609 and 1639	1
1605	Lever carrying Feed Control Rod 1615	1	1655	Shouldered Pin for 1604 and 1611	3
1606	Bracket carrying Sucker Bar Sucker	1	1656	Distance Washer	3
1607	Sucker	8	1657	Washer for 1628	1
1608	Tap Plug for Sucker	8	1658	Bush for 1609	1
1609	Lever embodying Automatic Throw-off	1	1664	Clamping Nut	1
1611	Lever coupling 1604 to 1606	1	2209	Knurled Screw	1
1612	Trunnion for carrying 1615 in 1605	1	Q 1	Taper Pin for 1655, N 72, 2,5×22 mm	2
1613	Threaded Adjusting Rod for 1604	1	Q 2	Taper Pin for 1655, N 72, 2,5×18 mm	1
1615	Feed Control Rod with Knurled Sleeve and Stop collar	1	Q 4	Hexagon Screw for 1606, N 46/1, 8×30 mm	1
1617	Sucker Bar	1	Q 5	Hexagon Screw for fixing 1601, N 47, 12×35 mm	4
1619	Knurled Adjusting Nut	4	Q 6	Pin for 1642, N 71, 4 × 36 mm	1
1622	Plunger for Automatic Throw-off	1	Q 7	Cheese-headed Screw fixing 1607, N 48/1, 5 × 16 mm	8
1624	Spiral Spring for 1609	1	Q 8	Cheese-headed Screw for 1639, N 48/1, 6 × 16 mm	2
1625	Washer for Tap Plug 1608	8	Q 9	Grub Screw for 1602, 1603 and 1605, N 53, 8 × 8 mm	3
1628	Shouldered Pin for 1604	1	Q 10	Rivet, N 77/2, 2 × 14 mm	1
1630	Sucker Bar Slide Rod	1	Q 11	Hexagon Screw fixing 1641 to 1603, N 46/1, 8 × 20 mm	2
1631	Flexible Tubing to Sucker Bar	1	Q 12	Taper Pin for 1641, N 72, 5 × 60 mm	1
1632	Feed Control Bar attached to 1605	1	Q 13	Cheese-headed Screw for 1632, N 48/1, 4 × 10 mm	2
1634	Flexible Tubing connecting 0114 with 1640	1	Q 14	Taper Pin for 1642, N 72, 3 × 24 mm	1
1636	Spindle for 1605	1	Q 15	Split Pin, N 75, 2 × 20 mm	1
1637	Spindle for 1606	1	Q 16	Taper Pin for 1615, N 72, 2,5 × 16 mm	2
1638	Spring Ring in 1609	1	Q 17	Taper Pin for fixing 1602 to 1630, N 72, 4 × 36 mm	1
1639	Suction Nozzle for 1609	1	Q 18	Grub Screw fixing 1636 in 1605, N 53, 8 × 12 mm	1
1640	Tube for same	1	Q 19	Taper Pin for 1601, N 72, 5 × 50 mm	2
1641	Guide Plate attached to 1603	1	Q 20	Split Pin for 1615, N 75, 4,6 × 10 mm	1
1642	Knurled Sleeve attached to 1649	1	Q 21	Guide Pin in 1617, N 72, 3 × 20 mm	1
1643	Bush in 1601	2			
1644	Knurled Locking Nut for 1650	1			
1645	Bush for 1606 narrow side	1			
1646	Bush for 1606 wide side	1			
1647	Bracket Stop for Automatic Throw-off	1			
1648	Shouldered Screws for fixing 1647	2			
1649	Plunger Catch for Automatic Throw-off	1			






TABLE R. IMPRESSION THROW-OFF LEVER

Part No.	Description	Quantity	Part No.	Description	Quantity
1701	Balled Handle	1	R 1	Hexagon Nut for 1705, N 62, 12×9 mm	1
1702	Knurled Locking Nut for 1703	1	R 2	Washer for 1705, N 65/1, 12,5 mm	1
1703	Regulating Sleeve for Impression	1	R 3	Grub Screw for 1706, N 53, 6×8 mm	1
1704	Impression Throw-off Rod	1	R 4	Hexagon Screw fixing 1707, N 46/1, 8×22 mm	3
1705	Shouldered Pin for fixing 1704	1			
1706	Stop Ring for 1703	1			
1707	Impression Lever Stop	1			




T A B L E S. A I R P U M P

Part No.	Description	Quantity	Part No.	Description	Quantity
1801	Air Pump Cylinder	1	1832	Bottom of Pump Cylinder	1
1802	Cover for same	1	1634	Flexible Air Tube connecting 1815 with 2110	1
1803	Piston for 1801	1	0637	Bush for 1802	1
1804	Piston Ring for 1803	3	S 1	Lubricator in 1805 and 1814, No. 1, N73	2
1805	End Piece for 1809	1	S 2	Taper Pin fixing 1805 to 1809, N 72, 6,5×36 mm	1
1807	Nozzle for 1801	1	S 3	Hexagon Nut for 1808 and 1809, N 61/1, 12 mm	3
1808	Crank Driving Pin in 1805	1	S 4	Hexagon Screw fixing 1802 and 1832, N 46/1, 8×22 mm	6
1809	Piston Rod	1	S 5	Washer for S7, N 65/1, 6,2 mm	1
1811	Washer for 1808	2	S 6	Cheese-headed Screw for fixing 1813, N 48/1, 4×6 mm	1
1812	Air Regulating Screw in 1802	1	S 7	Cheese-headed Screw fixing 1821 to 1824, N 48/1, 6×10 mm	1
1813	Flat Clip for fixing 1814	1	S 8	Grub Screw fixing 1824, N 53, 4×12 mm	1
1814	Oil Pipe	1			
1815	Two-way Tap with brass connection in 1801	1			
1818	Rubber Tube for connecting 1807 with 0114	1			
1821	Leather Washer for 1824	1			
1823	Bush for 1801	1			
1824	Clack Valve	1			
1825	Pin fixing 1824	1			
1826	Compression Spring for 1824	1			
1828	Bush for 1805	1			




T A B L E T. C L U T C H L E V E R

Part No.	Description	Quantity	Part No.	Description	Quantity
1901	Clutch Lever	1	1936	Screwed Extension Piece coupling 1907 to 1935	1
1907	Hand Grip attached to 1936	1	1937	Cheese-headed Screw fixing 1931	1
1910	Guide Pins operating 0402	2	T 1	Taper Pin, N 72, 5×45 mm	1
1916	Return Spring for Lever 1901	1	T 2	Taper Pin, N72, 6,5×32 mm	1
1920	Pin coupling 1901 to 0436	1	T 3	Rivet, N 77/2, 4×14 mm	1
1928	Bar Support for 1901	1	T 4	Pin, N 71, 3×32 mm	1
1930	Sleeve carrying Spring 1916	1	T 5	Rivet attaching 1930 to 1931, N 77/1, 4×10 mm	2
1931	Fixing Plate attached to 1930	1	T 7	Split Pin fixing 1920, N 75 3×25 mm	1
1932	Collar for 1928	1	T 6	(Should be T2)	1
1933	Spindle carrying Hand Grip 1907, 1936 and 1935	1			
1934	Coil Return Spring for Stop 1935	1			
1935	Clutch Engagement Stop attached to 1936	1			




T A B L E U. F R I S K E T B A R

Part No.	Description	Quantity	Part No.	Description	Quantity
2001/8	Bearing Bracket carrying 2002	2	2012	Plates fixing Frisket Fingers	2
2002	Frisket Bar	1	2013	Frisket Finger, narrow	1
2003	Threaded Pillar carrying Spring 2004	1	U 1	Hexagon Nut for 2010, N 62, 6×5 mm	2
2004	Tension Spring attached to 2005	1	U 2	Cheese-headed Screw for fixing 2001/8, N 48/1, 8×22 mm	4
2005	Lever attached to 2002	1	U 3	Taper Pin, N 72, 2,5×24 mm	1
2006	Frisket Finger, wide	1	U 4	Washer for 2010, N 65/1, 6,2 mm	2
2009	Cross Frisket	1			
2010	Screw fixing Frisket Fingers	2			



T A B L E V. G U A R D S

Part No.	Description	Quantity	Part No.	Description	Quantity
2101	Side Guard Rail	1	V 1	Cheese-headed Screw fixing 2108, N 48/1, 4×4 mm	2
2102	Bracket carrying Front Guard	1	V 3	Taper Pin indicating air stream fitted to 2105	1
2103	End Bearing for Front Guard	1	V 4	Cheese-headed Screw fixing 2109, N 48/1, 8×15 mm	2
2105	Front Guard	1	V 6	Name Plate, N 122	1
2106	Side Guard	1	V 7	Copper Rivet fixing V 6, N 78, 2×4 mm	6
2107	Pin carrying End Bearing 2103	1	V 8	Hexagon Screw fixing 2116, N 46/1, 10×30 mm	1
2108	Guard for Inking Cylinder	1	V 10	Hexagon Nut for 2118, N 62, 10×7 mm	1
2109	Guard covering 0502	1	V 14	Washer for 2107, N 65/1, 10,3 mm	1
2110	Iron Tube Connection to Blower Tube	1	V 15	Hexagon Nut for fixing 2101, N 62, 16×11 mm	4
2111	Blower Tube with Plug and Connecting Piece	1	V 16	Rivets fixing 2120, N 78, 3×6 mm	2
2112	Fixing Nut for 2111	1	V 17	Split Pin for 2107, N 75, 2×20 mm	1
2113	Elbow Piece connecting 2110 to 2111	1	V 18	Cheese-headed Screw fixing 2115, N 48/1, 5×12 mm	1
2115	Guard for 0502 and Main Bearing Oil Pipes	1			
2116	Bracket carrying Blower Tube	1			
2117	Clamping Bush	1			
2118	Bolt	1			
2120	Bracket	1			



T A B L E W. S H E E T S T E A D I E R

Part No.	Description	Quantity	Part No.	Description	Quantity
2201	Clamping Sleeve for 2206 carrying 2212	1	2212	Bar fixed to 2201 carrying 2203	1
2203	Holder with Sheet Steadier Spring	2	W 1	Washer for 2206, N 65/1, 10,3 mm	1
2206	Bar for 2201	1	W 2	Hexagon Nut fixing 2206 to Lay Standard 1008, N 62, 10×7 mm	1
2209	Knurled Screw for adjusting Sheet Steadier Spring	2	W 3	Taper Pin fixing 2212 to 2201, N 72, 2,5×24 mm	1
2240	Knurled Screw for clamping 2203 to 2212	2			
2241	Knurled Screw clamping 2201 to 2206	1			





TABLE X. DELIVERY SLIDES FOR SMALL SIZES


Part No.	Description	Quantity	Part No.	Description	Quantity
2301	Clamping Piece for Delivery Slide	4	2201	Clamping Sleeve fixed to 2302	1
2302	Rod carrying Delivery Slides	1	2211	Knurled Screw clamping 2201 to Lay Standard	1
2303	Delivery Slide	4	X 1	Taper Pin fixing 2302 to 2201, N 72, 2,5 × 24 mm	1
2305	Knurled Clamping Screw for 2301	4			





T A B L E Z. S H E E T C O U N T E R

Part No.	Description	Quantity	Part No.	Description	Quantity
2501	Sheet Counter	1	Z 2	Taper Pin fixing Z3 to 2506, N 72, 2,5×24 mm	1
2503	Striking Lever	1	Z 3	Collar for 2506, BN 108, 10×10 mm	1
2504	Push Rod operating 2503	1	Z 4	Screw with Tommy holes, N 82, 6×16 mm	1
2505	Trunnion coupling 2503 to 2504	1	Z 5	Taper Pin fixing 1621 to 2504, N 72 2,5×18 mm	1
2506	Threaded Pin carrying 2503	1			
2507	Leather Washer	1			
1621	Adjusting Ring	1			
Z 1	Cheese-headed Screw fixing 2501, N 48/1, 5×12 mm	2			




Copyright by Schnellpressenfabrik A.-G. Heidelberg  
Heidelberg (Germany)






## DIAGRAM OF CONNECTIONS

For:— SPECIAL SINGLE-PHASE SQUIRREL-CAGE  
MOTOR WITH SIX TERMINALS.



Connections for  
Contrary  
Rotation



P. No. 103A